

USING SPOT GEN3

This Quick Reference Guide is here to help you learn the many functions of your SPOT Gen3.



POWER LIGHT — Press the power button to turn SPOT on; LED's will illuminate. Press and hold the power button until it blinks rapidly to turn SPOT off.

GREEN — Batteries are good.

RED — Change batteries as soon as possible.

GPS LIGHT — Notifies you whether SPOT is able to see the GPS satellites and obtain your GPS location.

GREEN — The GPS light blinks green if SPOT sees the GPS satellites and is looking for / has found your GPS location.

RED — The GPS light blinks red if SPOT cannot see the GPS satellites and/or can't find your GPS location. (If the GPS light blinks red, you should move to a location with a clearer view of the sky.)

GPS

MESSAGE SENDING LIGHT — Notifies you whether or not your most recent message was transmitted.

GREEN — The message light blinks green if SPOT sent the most recent message.

RED — The message light blinks red if SPOT didn't send the most recent message.



Enjoy the extended battery life of your SPOT Gen3. There are multiple options to powering your SPOT. For more details on battery usage, visit FindMeSPOT.com/gen3.

POWER OPTIONS

- ▶ 4 AAA Energizer® Ultimate Lithium 8x batteries (L92)
- ▶ 4 AAA Energizer® NiMH rechargeable batteries (NH12)
- ▶ Line Power with a 5v USB connection

S.O.S.

S.O.S. — Press and hold the button until the light blinks green. Sends a message every 5 minutes until cancelled. To cancel, press and hold button until the light blinks red. **Activation of the SOS button goes directly to the GEOS International Emergency Rescue Coordination Center and should only be used in critical, life threatening situations.**



HELP/SPOT ASSIST — Press and hold the button until the light blinks green. Sends a message every 5 minutes for 1 hour. To cancel, press and hold button until the light blinks red. **This feature should be used in a non-life threatening situation, i.e. your car breaks down.**



CHECK IN — Press and hold the button until the function light blinks green. To ensure delivery, leave active for 20 minutes. **This activates a pre-programmed message along with your GPS location.** To cancel unsent messages, simply press and hold the button until the light blinks red.



CUSTOM MESSAGE — Press and hold the button until the function light blinks green. To ensure delivery, leave active for 20 minutes. **This activates a custom message that you create and set up before leaving on your adventure. This message is sent to all your contacts with your GPS location. (Example: My bike ride was a success! I'm headed home.)** To cancel unsent messages, simply press and hold the button until the light blinks red.



TRACKING — Press and hold the button until the light blinks green. SPOT will send your tracks in near real time to your SPOT Share Page. To cancel Tracking, simply press and hold the button until the light blinks red. With an Unlimited or Extreme Tracking plan, change your tracking rate to 2½, 5, 10, 30, or 60 minutes. SPOT Gen3's built-in vibration sensor sends tracks only when you are moving, conserving battery life. **Learn about the different Tracking rates at FindMeSPOT.com/Services or upload your tracks to SPOTAdventures.com.**